

## INSTALLING THE MATRIX F22

### 1. Unpack



Remove franking system, scales, consumables and cables from shipping box.

### 6. Position the catcher tray



Position the catcher tray on the left of the franking system.

### 2. Connect mains lead



Connect the mains lead with the mains adapter. **Attention! Do not connect the mains adapter with the power outlet socket!**

### 7. Connect the franking system with mains



Connect the franking system with the power outlet socket. Wait for the start-up sequence to be completed.

### 3. Connect power supply



Connect the power supply (right-angle plug) as shown to the franking system.

### 4. Connect the cables



Connect from the left to the right:  
- The scales' cable  
- The network cable.

### 5. Position the scales



Position the scales stand behind the franking system and put the scales on it.