

INSTALLING THE MATRIX F62

1. Unpack



Remove franking system, scales, consumables and cables from shipping box.

6. Prepare the Ink-Jet Cassette



Remove the two protector strips of the new Ink-Jet Cassette being careful not to touch the gold coloured contact points.

2. Mount the feeder to the franking system



Press the release button to mount the feeder to the franking system.

7. Insert the Ink-Jet Cassette



Insert the new Ink-Jet Cassette by pinching the grips of the new cassette and pushing it in to the franking machine.

3. Connect the cables



Connect from the left to the right:
- The mains lead (do not connect the other end with mains)
- The scale cable
- The network cable

8. Position the catcher tray



Position the catcher tray on the left of the franking system.

4. Position the scales



Position the scales stand behind the franking system and place the scales on to it.

9. Switch on the franking system



Plug power cable in to mains. Switch the franking system on.

5. Insert the Label Box



Insert the Label Box.