


LOADING POSTAGE CREDIT

1. Connecting franking system with network




Make sure that the network connection is first set up correctly.

2. Select Account




Press "Admin" button in bottom right hand corner of screen.

3. Enter PIN




Enter your PIN (1234) and confirm with "OK".

4. Select further information




Main Menu: Press the "i" key in the top right of screen.

5. Select spanner option




Counter Readings: Select the spanner in the top right of screen.

6. Open Menu "Setup 2"




Menu Setup 1: Press the arrow top right.

7. Select "FramaOnline2"




Menu Setup 2: Select "FramaOnline2" bottom right of screen.

8. Select „Re-set“



Menu FramaOnline2: Select "Re-set" in the bottom left of screen.

9. Re-set Value



Enter the Re-set Value desired. The postage credit will now be loaded.
*Country-specific differences